


Creator
家用绣花机


拆箱说明

①




1. 剪开纸箱上的封箱胶带
2. 打开纸箱

②




1. 取下线板。
2. 取出框架支架 (1)。
3. 移除塑料袋 (2)。
- 3a. 塑料袋 (2) 中包含的配件：
 - a. 70×50 mm 绣框 (4) :1 套
 - b. 110×110 mm 绣框 (5) :1 套
 - c. 190×140 mm 绣框 (6) :1 套
 - d. 310×210 mm 绣框 (7) :1 套
 - e. 380×210 mm 绣框 (8) :1 套

③




1. 抓住纸箱侧面的塑料提手, 向上提起纸箱

④




1. 从泡沫外侧取下绣框固定座 (1)
2. 取下帽架 (2)

⑤




1. 从两侧将泡沫拿开

⑥



1. 打开塑料袋
2. 从底部抬起机器, 将其从塑料包装中取出
建议由两人共同完成此操作

⑦



1. 取出工具箱